

**OPERATING  
INSTRUCTIONS**

+


**LOGBOOK**

**FOR THE  
WINDTURBINE**



**LAGERWEY WINDTURBINE BV**

Postbus 279  
3770 AG Barneveld  
Tel.: 0342-422724 / Fax : 0342-422861



## Table of contents

### 1. Operating instructions windmill.

- |        |   |
|--------|---|
| Page 1 | 1. Starting the windmill.<br>2. Yawing.<br>3. Stopping the turbine.<br>4. Caution.<br>5. Error messages.<br>6. Cable twist control. |
| Page 2 | Display information.  |
| Page 3 | Safety precaution before maintenance.   |

### 2. Frontview controlpanel in controlhousing.

### 3. Alarm discription.

- |           |                                |
|-----------|--------------------------------|
| page 1..3 | What to do by alarm.           |
| page 3    | Instructions to replace fuses. |

### 4. Technical drawings.

### 5. Technical data and diagrams.

Benaming

**OPERATING INSTRUCTION LW 18/80 PLC**

Ref.:

NEN - ISO 9001 - 4.5



LAGERWEY WINDTURBINE BV  
Hanzeweg 31  
3771 NG Barneveld  
Tel.: 0342-422724 / Fax : 0342-422861

Opsteller:  
J.R. *[Signature]*

Gekontroleerd:  
K.W. *[Signature]*

Beheerdeer:  
J.R.

Nummer

WI 4.9-1.3-1.10.28a-E

Blad:

Datum :

07-04-93

Wijz.:

a : 15-10-93

## OPERATING INSTRUCTIONS WIND MILL

Operated with PLC

We suppose that the windmill rotor is not locked.

### Starting the Windmill:

1. Turn Main Switch ( Q1 ) to 1
2. The PLC display should now read out the wind speed in m/s, the rotor rpm, the kW and the kW hours and read CONNECTED 10 min wind <>. Please note that display could take a few seconds to appear.
3. The PLC will turn the windmill out of the wind and begin measuring ten minute average windspeed.

### Yawing:

Yawing is the turning of the generator assembly. Normally the windmill will control the Yaw automatically. After a STOP command or an ALARM the windmill will yaw 110 degrees out of the wind. Manual Yawing is done by pressing the <-, -> keys on the PLC display panel. If all else fails, use the blue mutual buttons below the control panel to directly close the Yaw contactors.

### Stopping the turbine:

Push the STOP button on the PLC control panel and the generator assembly will yaw out of the wind and stop.

### CAUTION

Check to be sure that there are no error messages on the display after the main switch has been opened and closed again. If unusual displays are observed remedy immediately.

### Error messages:

Error messages are accompanied by the number indicating the type of error and what the wind mill control is doing about it. See the Alarm discription,in this manual you may receive further instructions on what you can do to return the mill to normal operating condition.

### Cable twist control:

After the cable has been twisted approximately three turns, the mill will untwist the cable if the windspeed is less than 10m/sec. If the wind speed is greater than 10 m/sec. and less than 20m/sec the mill will only untwist the cable for 1 turn. If the wind speed is greater then 20 m/sec the mill will wait with untwist until the windspeed is less than 20 m/sec.

Benaming	OPERATING INSTRUCTIONS LW 18/80 PLC				Ref.:	NEN - ISO 9001 - 4.5	
	LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: J.R. 	Gekontroleerd: K.W. 	Baheerde: J.R.			a : 15-10-93

Display information:

- A. By pressing F4 and 0 together and then pressing 0 alone, following displays are possible. To return to normal display press RESET.
- previous hour windspeed and kWh
  - previous day windspeed and kWh
  - previous week windspeed and kWh
  - previous month windspeed and kWh
  - peak 5 minute gust
  - total operating hours of the mill
  - Windvane , M.W.O. powermeasuring , version number
- B. To display windspeed and kWh and the date ,press F4 and 1 together and then pressing 1 alone, following displays are possible. Pressing the Reset key will return you to normal display.
- windspeed and kWh of the previous two months by day.
- C. To display windspeed and kWh of the previous two years by month press F4 and 2 together and then pressing 2 alone, following displays are possible. Pressing the Reset key will return you to normal display.
- windspeed and kWh of the previous two years by month, liver hours availability.
- D. To display the last 200 alarms and reset times press F4 and 3 together and then pressing 3 alone,following displays are possible. Pressing the Reset key will return you to normal display.
- Date , time and alarmnumber.

Meaning of the alarm numbers:

0 - reset alarm	107 - alarm inverter temp.	115 - alarm yaw motor failure
100 - alarm grid failure	108 - alarm imbalance	116 - alarm rotor brake failure
101 - alarm inverter failure	109 - alarm wind	117 - alarm K1 , fuses failure
102 - alarm Q2 is off	110 - alarm low battery	118 - alarm max power
103 - alarm K2 failure	111 - alarm WS sign. failure	
104 - alarm power failure	112 - alarm K1 failure	
105 - alarm overspeed	113 - alarm cable tw. failure	
106 - alarm RPM sign. failure	114 - alarm windvane failure	

Benaming	OPERATING INSTRUCTION LW 18/80 PLC			Ref.:	NEN - ISO 9001 - 4.5	
	LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: J.R. 	Gekontroleerd: K.W. 	Beheerder: J.R.		
		Nummer: WI 4.9-1.3-1.10-28a-E	Blad: 2 / 3	Datum: 07-04-93	Wijz.:	a : 15-10-93

SAFETY PRECAUTION BEFORE MAINTENANCE:

1. Be sure that you are familiar with the operation of this mill before attempting any maintenance procedures. Check with your dealer if in doubt.
2. To stop windmill press STOP. Wait until mill yaws out of wind by itself. Then turn off the main switch to position 0
3. To lock the rotor, engage the lock pin into the generator coupling. This procedure is to be done only if rotor is completely stopped or damage will result.

**Record all maintenance procedures and events in turbine log book.**

Recordings in the logbook are:

- Adjusted setpoints.
- Alarms and incidents.
- Maintenance en inspection-times.
- Established deviations by inspection.
- Installed alterations.
- Names of persons of dealers who carry out the maintenance procedures on the wind mill.

Benaming	OPERATING INSTRUCTION LW 18/80 PLC			Ref.:	NEN - ISO 9001 - 4.5	
 LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: J.R.	Gekontroleerd: K.W.	Beheerder: J.R.			
	Nummer: WI 4.9-1.3-1.10.28a-E	Blad: 3 / 3	Datum: 07-04-93	Wijz.:	a : 15-10-83	

## SPECIAL FUNCTIONS :

Press F4 and 0 simultaneously for first text and then only 0 for next text.

= kWhs and windspeed in previous hour, day, week, month,  
the max. power in 5 min. and the totaled delivery hours from the turbine.

Press F4 and 1 simultaneously for first text and then only 1 for next text.

= date (day, month) and kWhs and windspeed from previous 60 days.


Press F4 and 2 simultaneously for first text and then only 2 for next text.

= date (day, month) and kWhs, windspeed and delivery hours in the  
previous 24 months.

Press F4 and 3 simultaneously for first text and then only 3 for next text.

= The last 200 alarms and reset times

Press RESET for the normal status display.



Eurp. proj.-	Benaming :	FRONTVIEW CONTROLPANEL IN CONTROLHOUSING			Ref.:
					NEN - ISO 9001-4.5
	LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: K.W. 	Gekontroleerd: J.R. 	Beheerder: J.R.	
	Nummer: E-ED-2063d	Blad : ...1... van ...1...	Datum: 28-06-91	Wijz.:	a : 09-01-92 b : 22-01-92 c : 05-06-92 d : 27-06-94

## ALARM DESCRIPTION

If the display shows an alarm condition, follow the instructions, which you can read after this.  
To return to normal text press F4 and not RESET.

If text reads that you should call Lagerwey, do not reset until you have called your dealer.  
IMPORTANT: Only press RESET after you have followed all directions.

### ALARMNR.

### DESCRIPTION

1 " ALARM IMBALANCE"

The wind mill has imbalance in the rotor. This will cause the turbine to YAW out of the wind.  
Check for ice or damage and consult your dealer.

2 " ALARM OVERSPEED"

This will cause the turbine to YAW 110 degrees out of the wind. At this point a blade inspection should be done in consultation with your dealer. The display can be returned to normal by pressing the RESET key.

3 "ALARM INVERT.TEMP."

The inverter is overheated. If this occurs, the turbine will YAW out of the wind and restart when the temperature is within normal range.

The alarm will remain displayed on the screen.

If alarm occurs a second time the turbine will not restart and the RESET key followed by the START key must be pushed.

Clean all the air intakes ( 2 ) and be sure that fans are functioning ( 4 ), a few minutes after a restart is attempted, and mill generates power.

4 "ALARM INVERT. FAIL."

The turbine will YAW out of the wind. Check all fuses and circuit breakers F3 and F4. Replace defective fuses and/or reset circuit breakers.

Push the RESET key followed by the START key and turbine will restart.

If the alarm reoccurs, the inverter must be checked. Call your dealer.

5 " ALARM GRID FAILURE"

Supply grid error past or present.

The turbine will, depending on windspeed, YAW until available voltage is unable to overcome friction on yaw gear. Some delay time is normal since capacitor bank must be full before voltage is rise.

Turn main switch off and check for defective fuses and whether grid is normal.

To restart, turn main switch on, press the RESET key and then the START key.

The turbine will then measure the 10 minute average wind speed and start automatically if this reading is sufficient. To remove error display press RESET.

If error reoccurs consult your dealer.

Benaming	ALARM INSTRUCTION-LIST				Ref.:	NEN - ISO 9001 - 4.5	
	LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: J.R. <i>AL</i>	Gekontroleerd: <i>dw</i>	K.W.	Beheerder: J.R.		
	Nummer: WI 4.9-1.3-1.10-29a-E	Blad: 1 / 3	Datum: 07-04-93	Wijz.:	a : 20-10-93		

- 6 "ALARM Q2 IS OFF"  
 The fuse watching switch is tripped. The turbine will YAW out of the wind.  
 Replace the defective fast blow fuses with main switch off.  
**CAUTION: Fuses may be hot.**  
 Reset the Q2 switch and turn main switch on. Press the RESET key and then the START key. The turbine will then measure the 10 average minute wind speed and start automatically if this reading is sufficient. If error reoccurs, consult your dealer.
- 7 "ALARM WIND SP.> 25."  
 Excessive wind. If the windspeed is or was greater than 25 m/sec for four seconds, the turbine will YAW out of the wind.  
 The turbine will restart automatically once the ten minute falls below 25m/sec.
- 8 "ALARM LOW BATTERY"  
 If this alarm displays, the battery needs to be replaced within one week by your dealer.  
 The turbine will YAW out of the wind.  
 Twelve hours of operation are still possible by pressing the RESET button.  
 After this twelve hours have elapsed, the turbine will once again YAW out of the wind and remain until this alarm situation is corrected.
- 9 "ALARM W.VANE sign. FAIL."  
 Windvane signal is loss. The turbine will use its EMERGENCY YAW CIRCUIT to turn out of the wind and still be connected with the main power supply. Press the RESET key, followed by the START key, to restart the turbine. If this does not work the windvane may be need to be serviced by your dealer.
- 10 "ALARM RPM sign.FAIL."  
 RPM signal is loss. In this case the turbine will YAW 110 degrees out of the wind.  
 Call your dealer to determine corrective procedure.
- 11 "ALARM W.S.sign.FAIL."  
 Anemometer signal is loss. In this case the turbine will YAW out of the wind.  
 Call your dealer to determine corrective procedure.
- 12 "ALARM10 MIN. WIND"  
 The PLC is measuring the ten minute wind average.  
 If the average is below 25m/sec and above 3m/sec, the turbine will start automatically and the display will change to reflect what the mill is doing.
- 13 "ALARM YAW mot.FAIL."  
 Check and reset Q3 if necessary. Use the blue yaw drive keys to YAW the turbine into the wind.  
 If this fails or the relay trips again, call your dealer.  
 If successful press the RESET key, followed by the START key. The turbine will automatically YAW into the wind.  
**CAUTION: During the alarm the turbine will not attempt to YAW out of the wind, and if a second alarm occurs the turbine will attempt to engage the EMERGENCY YAW CIRCUIT and YAW of the wind as much as possible.**

Benaming	ALARM INSTRUCTION-LIST				Ref.:	NEN - ISO 9001 - 4.5	
	LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: J.R. <i>[Signature]</i>	Gekontroleerd: K.W. <i>[Signature]</i>	Beheerder: J.R.			

- 14 "ALARM K2 FAILURE"  
K2 contacter does not close. The turbine will YAW out of the wind. Call your dealer to determine corrective procedure.
- 15 "ALARM CABLE TW.FAIL."  
Outside limits of YAW operation or a micro-switch has failed. The turbine will YAW out of the wind. Call your dealer to determine corrective procedure
- 16 "ALARM K1 FAILURE"  
K1 contactor does not close. The turbine will YAW out of the wind. Call your dealer to determine corrective procedure.
- 17 "ALARM MAX. POWER"  
The power of the mill is too high. Call your dealer to determine corrective procedure.
- 18 "ROTOR BRAKE FAILURE"  
The rotor brake doesn't work anymore when the turbine is out of the wind.  
The turbine will YAW back to 90 degrees out of the wind, try to stop rotating.  
Call your dealer to determine corrective procedure.

#### ALARM INSTRUCTION LIST

If there is a fuse(s) -failure and it must be replaced, the following numbering must be followed.

1. Stop the turbine by pressing the STOP key.  
If the turbine is yawing in emergency mode wait until the turbine has stopped its yawing before pressing any keys.  
**NOTE: The rotor may be still be turning after emergency yaw procedure is complete**
2. Turn OFF the main switch Q1
3. Using the proper tool remove and replace defective fuses.  
**NOTE: Fuses may still be hot.**
4. Turn Q1 on and press RESET followed by the START key.
5. The turbine will now measure the 10 minute wind speed.  
The display must be returned to normal.
6. If the wind speed fails within limits the turbine will restart automatically.

Benaming	ALARM INSTRUCTION-LIST			Ref.: NEN - ISO 9001 - 4.5
	LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller : J.R. 	Gekontroleerd : K.W. 	Baheerde : J.R.
	Nummer : WI 4.9-1.3-1.10.29a-E	Blaad : 3 / 3	Datum : 07-04-93	Wijz. : a : 20-10-93


**Elektrotechnical Program Adjustments.**

**LW 18/80 WD,AL**


<u>Part</u>	<u>Name</u>	<u>Type</u>	<u>Program</u>	<u>Value</u>
PLC	ID nr.		Identitiy number	Each turbine has his own number (Standard = 5000)
PLC	DELAY 1	LOW->HIGH	on 5	= 5 sec
PLC	DELAY 2	HIGH->WAIT	on 90	= 90 sec
PLC	DELAY 3	WAIT ->LOW	on 2	= 2 sec
PLC	DELAY 4	Disconnect.Cap.K2	on 100	= 100 sec
PLC	Windspeed 3	cut out limit	on 25	= 25 m/sec
PLC	Out of Wind 1	Degrees out of wind	on 115	= 115 Degrees
PLC	Time out off the wind after wind alarm (10...720 min.)		on 10	= 10 min.
PLC	Windspeed 1	Yaw stop limit	on 2	= 2 m/sec
PLC	Windspeed 2	Cut in limit (0...25 m/s)	on 25	= 25 m/sec
PLC	RPM1	Cut in limit	on 60	= 60 RPM
PLC	Dead Angle	Windvane	on 10	= 10 Degrees
PLC	LOW / HIGH	Switchpoint	on 25	= 25 kW
PLC	0 kW	Adjustment 0 kW display	on 51	= 51
PLC	Mill Type	C.T.Adjustment	on 80	= 150 / 5
PLC	K 20	cut in piont K20	on 35	= 35 kW
Relay	U 5	=DUR SP hyst AC T	on 0 on 0,2 on 0	= 0 % hystereses = 100 Generator Volt. = 0 sec
Relay	F 8	=DUFRN min =DUFRN max T	on -5 on +10 on 0	= 5 % Undervoltage = 10% Overvoltage = 0 sec
Mutator PCB	U3	= Delta low Delta high	on 135° on 150°	= 135° Firing angle = 150° Firing angle
Protect.	Q 2	= Motor protection switch	on 0,1	= 0,1 Amp Fusecontrol
Protect	Q 3	= Motor protection switch	on 1,6	= 1,6 Amp Yawmotor
Timerelay	K 100	= VWS time sector value	on 3 s on 30	Pulstime = 3 sec
Timerelay	K 101	= ARS time sector value	on 10 min	only with alarmdialer
Timerelay	K 102	= AHS time sector value	on 10 s	minalarmdial delay
Timerelay	K 103	= ERS time sector value	on 7 on 3 s on 20	W.D.switch off delay W.D.switch on delay = 70 sec = 2 sec

EEPROM version: spdlh.23 spdlh.23 spdlhm.p24 spvrolyk.12 spwka.14

Benaming	ELECTRICAL ADJUSTMENTS LW 18/80 WD,AL			Ref.:
			NEN - ISO 9001 - 4.5	
 <b>LAGERWEY WINDTURBINE BV</b> Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller:	Gekontroleerd:	Beheerdeer:	
	K.W. <i>[Signature]</i>	<i>[Signature]</i>		
	Nummer:	Blad:	Datum:	Wijz.:
	WI 4.9-1.3-1.10-32c-E	1 / 1	03-05-93	a : 19-04-94 c : 30-05-95



Eurp. prof.	Benaming : FRONTVIEW CONTROLHOUSING			Ref.:
	LAGERWEY WINDTURBINE BV		Gekontroleerd: J.R.	NEN - ISO 9001-4.5
Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: K.W.		Blad: ... van ...	Datum: 4-10-91
	Nummer: <b>E- ED-2061c</b>		Wijz.:	b : 07-10-92 c : 04-01-94



Eurp. proj.	Benaming :	+ WATCH DOG RELAY			Ref.:
		Spec. filter 80 kW			NEN - ISO 9001-4.5
	LAGERWEY WINDTURBINE BV	Opsteller: K.W.	Gekontroleerd: <i>W</i>	Beheerder:	
	Postbus 279 3770 AG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Nummer: E- ED-2248 80kW	Blad : 1...van.1...	Datum: 01-05-95	Wijz.:

**DESCRIPTION COMPONENTS**

Name	Description	Partnumber
B1	Temperatureswitch 90°C NC	E0147
B2	Temperatureswitch 60°C NO	E0148
B3	Anemometer	E2360
B4	Revolution counter	E2346
B5	Windvane	E2372 ▲ a
B6	Fan at Diode-cooler	E0061
B7	Fan at Mutatorcooler	E0061
B8	Fan at controlbox-door left	E0050,E0037
B9	Fan at controlbox-door right	E0050,E0037
C1	Capacitorbank Mainsfilter	E0273
C2	Capacitorbank Generator Delta-Low	E0282 ▲ a
C3	Capacitorbank Generator Delta-High	E0271,E0273
C4	Capacitorbank Generator Emergency Delta Low/High	E0286 ▲ b
C5	Capacitorbank Mainsfilter	E0270
C6	Capacitorbank Mainsfilter	E0273
E1	Heating chassis-controlbox	E0014
F1	Fuses Mutator superfast	E0182,E0481
F2	Fuses Controlsystem	E0490,E0750,E0780,E0810
F3	Earth leakage switch	E0471
F4	Trip circuitbreaker 6 Amp. for measuring- and controlcircuit	E0460
F5	Trip circuitbreaker 16 Amp. for controlcircuit	E0450
F6	Fuses Lightning - Arresters	E0500,E0760,E0790,E0820
F7	Lightning Arresters Mainsconnection	E0295
F8	Voltageprotection Relay Mainsconnection	E0252
F9,10	Overvoltage terminal D1,D2 Datawire at controlhousing	E0199
F11,12	Overvoltage terminal D1,D2 Datawire at chassiscontrolbox	E0199
F13,15,16	Overvoltage terminal Windvaneconnection at Chassiscontrolbox	E0199
F14	Overvoltage terminal + Windvaneconnection at Chassiscontrolbox	E0198
F17,18	Fuses Transformer	E1044,E2476
F19,20,21	Overvoltage terminal MWO. analog	E0199
F22	Overvoltage terminal MWO. digital	E0198
G1	Generator	


Eurp. proj.	Benaming :	ELECTRICAL DIAGRAM LW 18 / 80				Opties:	3
	LAGERWEY WINDTURBINE BV	Opsteller: K.W.	Gekontroleerd: <i>Uv</i>	Beheerdeer:		1	Filter 4
	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer: E- ES - 2116	Blad : -4 e	Datum: 1 of 11	Wijz.:	2	5
						b : 05-01-94	
						c : 11-07-94	
						d : 24-10-94	
						e : 30-12-94	

DESCRIPTION COMPONENTS		
Name	Description	Partnumber
K1	Generator- Mutator Connection-relay	E2410
K2.1	Filter Capacitor-relay 1	E2380
K2.2	Filter Capacitor-relay 2	E2381
K6	Capacitor Relay for Delta-Low Generator	E2380
K10	Generator- Yawmotor Connection Relay	E2395,E2420
K11	Yawmotor Turn Left Relay	E2395,E2420
K12	Yawmotor Turn Right Relay	E2395,E2420
K20	Filter Capacitor-relay 3	E2403
K100	Watch-dog pulse relay	E3800
K102	Watch-dog switch off relay	E3805
K103	Watch-dog switch on relay	E3810
K104	help relay mutator-printed circuit board	E3820,E3821
L1	Filtercoil	E1631
L2	Commutationcoil	E1621
L3	Directcurrent Coil	E1640
L4	Filtercoil	E1632 ▲
L5	Filtercoil	E1633 ▲
L6	Filtercoil	E1634 ▲
M1	Yawmotor	
P1	PLC in Controlhousing	E2330,E2340
P2	Controlpanel in Controlhousing	E2335,E2340
P3	PLC in Chassiscontrolbox	E2325
Q1	Mainswitch at Controlhousing	E0635,E0636
Q2	Fusescontrol-switch	E2438,E2439
Q3	Yawmotor Protection Switch	E2437
R1	Resistor 1kΩ kWh-Measuring Watt Transducer	E2470
R2	Resistor 500Ω Powermeasuring Watt Transducer	E2460
R3	Resistor 1kΩ for Anemometer	E2470

Europ. proj.	Benaming :	<b>ELECTRICAL DIAGRAM LW 18 / 80</b>				Opties:	3
	LAGERWEY WINDTURBINE BV	Opsteller: K.W. <i>[Signature]</i>	Gekontroleerd: <i>[Signature]</i>	Beheerder:		1	4 Filter
	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer: E- ES - 2116	Blad : -4 e	Datum: 2 of 11	Wijz.:	b : 05-01-94 c : 11-07-94 d : 24-10-94 e : 30-12-94	
Ref.: NEN - ISO 9001-4.5							

## DESCRIPTION COMPONENTS


Europ. proj.	Benaming :		Opties:	3	
			1	4	
			2	5	
	LAGERWEY WINDTURBINE BV	Opsteller: K.W. 	Gekontroleerd: 	Beheerder:	Ref.: <b>NEN - ISO 9001-4.5</b>
	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer: <b>E- ES - 2116</b>	Blad : <b>-4 e</b>	Datum: <b>3 of 11</b>	Wijz.: <b>12-01-93</b>
					b : 05-01-94
					c : 11-07-94
					d : 24-10-94
					e : 30-12-94



Eurp. proj.	Benaming :	ELECTRICAL DIAGRAM LW 18 / 80				Opties:	3
	LAGERWEY WINDTURBINE BV		Opsteller:	K.W.	Gekontroleerd:	<i>W.</i>	Ref.:
	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861		Nummer:		Blad :		NEN - ISO 9001-4.5
	E- ES - 2116		-4	e	4 of 11	12-01-93	b : 05-01-94 c : 11-07-94 d : 24-10-94 e : 30-12-94




LAGERWEY WINDTURBINE BV  
Hanzeweg 31  
3771 NG Barneveld  
Tel.: 0342-422724 / Fax: 0342-422861



20	21	22	23	24	25	26	27	28	29	30	31	32	33	34	35	36	37	38
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

CONTROLHOUSING / TOWERJUNCTIONBOX / CHASSISCONTROLBOX / CHASSIS




Eurp. proj.	Benaming :	ELECTRICAL DIAGRAM LW 18 / 80				Opties:	3
	K.W.	<i>b</i>				1	4 Filter
		Opsteller:	Gekontroleerd:	Beheerder:		2	5
<b>LAGERWEY WINDTURBINE BV</b>	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer: <b>E- ES - 2116</b>	Blad : <b>-4 e</b>	Datum: <b>5 of 11</b>	Wijz.:	b : 05-01-94 c : 11-07-94 d : 24-10-94 e : 30-12-94	

39 40 41 42 43 44 45 46 47 48 49 50 51 52 53 54 55 56 57

SUPPLY 220V

CONTROLHOUSING PLC P1- IN and OUTPUTS

INPUTS :	24 V SUPPLY	KWH MEASURING	MUTATOR	FUSE AND MAINS CONTROL	GEN.-MUT.CONN.	MUTATOR TEMPERATURE CONTR.
OUTPUTS :	GEN.-YAWMOT.CONN.	GEN.-MUT.CONN.	FILTERCAP.(DIS) CONNECTION	DELTA-CAP.-low	YAWING LEFT-TURN	



Eurp. proj.	Benaming :	<b>ELECTRICAL DIAGRAM LW 18 / 80</b>				Opties:	3
	LAGERWEY WINDTURBINE BV	Opsteller: <i>K.W.</i> Gekontroleerd: <i>W.</i> Beheerder: Ref.: NEN - ISO 9001-4.5				1	4 Filter
	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax: 0342 422861	Nummer:	Blad :	Datum:	Wijz.:	b : 05-01-94	
	E- ES - 2116	-4 e	6 of 11	12-01-93		c : 11-07-94	
						d : 24-10-94	
						e : 30-12-94	


58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74	75	76
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

CONTROLHOUSING PLC P1- IN and OUTPUTS



GEN.VOLTAGE,MEAS. FILTER IN

YAWING RIGHT-TURN

WATCH DOG



PAGE 7 / 10



PAGE 5 / 10

PAGE 7 / 10

Right turn Yaw relay		Filter Capacitor Relay 3	
K12		K20	
no	nc	no	nc
25	27	27	-
25	27	28	-
26	27	28	-
-	56	-	-

One shot switch relay

K100	
no	nc
73	-
-	-
-	-
-	-

Watch-dog switch off supply/switch on supply

K102		K103	
no	nc	no	nc
42	74	43	-
-	-	-	-
-	-	-	-
-	-	-	-

Eurp. proj.:	Benaming : ELECTRICAL DIAGRAM LW 18 / 80	Opties: 1    4 Filter 2    5
LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861		Opsteller: K.W. Gekontroleerd: WJ Beheerder: Ref.: NEN - ISO 9001-4.5
Nummer: E- ES - 2116 Blad : 4 e Datum: 12-01-93 Wijz.: b : 05-01-94 7 of 11		Datum: 12-01-93 Wijz.: b : 05-01-94 c : 11-07-94 d : 24-10-94 e : 30-12-94

77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----	----

PLC in CONTROLHOUSING

CONTROL PANEL IN CONTROLHOUSING


INP: POWERMEASURING

OUTP.:

COMMUNICATION-ENTRANCE

COMMUNICATION-ENTRANCE

SUPPLY 220V



Benaming :

**ELECTRICAL DIAGRAM LW 18 / 80**

Opties:	3
1	4
2	5



LAGERWEY WINDTURBINE BV  
Hanzeweg 31  
3771 NG Barneveld  
Tel.: 0342 422724 / Fax: 0342 422861

Opsteller:  
K.W.Gekontroleerd:  
W.

Beheerder:

Ref.:  
NEN - ISO 9001-4.5

Nummer:

Blad:

Datum:

Wijz.:

E- ES - 2116


-4 e

8 of 11

12-01-93

b : 05-01-94
c : 11-07-94
d : 24-10-94
e : 30-12-94

96	97	98	100	101	102	103	104	105	106	107	108	109	110	111	112	113	114	115
CONTROLHOUSING										T.JUNCT.BOX		CHASSISCONTROLBOX						
GEN.VOLTAGEMEASURING			COOLING CONTROLHOUSING			SOCKETOUTLET			+COMM.CONNECTION			SOCKETOUTLET		HEATING CONTR.BOX				





Eurp. proj.	Benaming :	ELECTRICAL DIAGRAM LW 18 / 80				Opties:	3
	LAGERWEY WINDTURBINE BV	Opsteller:	K.W.	Gekontroleerd:	WJ	Beheerder:	Ref.: NEN - ISO 9001-4.5
	Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer:		Blad :		Datum:	b : 05-01-94 c : 11-07-94 d : 24-10-94 e : 30-12-94
		E- ES - 2116	-4 e	9 of 11		12-01-93	

116 117 118 119 120 121 122 123 124 125 126 127 128 129 130 131 132 133 134

PLC in CHASSISCONTROLBOX


INP: 220V 24 V SUPPLY ANEMOMETER IMBALANCE RPM MEASURING CABLETWIST LIMITSWITCHES

OUTP:





Eurp. proj.	Benaming :	ELECTRICAL DIAGRAM LW 18 / 80				Opties:	3
	K.W.	<i>[Signature]</i>				1	4
LAGERWEY WINDTURBINE BV	Opsteller:	Gekontroleerd:	Beheerder:	Ref.:	2	5	
Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer: E- ES - 2116	Blad : -4 e	Datum: 10 of 11	Wijz.:	b : 05-01-94 c : 11-07-94 d : 24-10-94 e : 30-12-94		

## PLC IN CHASSISKAST



Eurp. proj.	Benaming :	ELECTRICAL DIAGRAM LW 18 / 80				Opties:	3
	K.W.	Gekontroleerd: <i>Loh</i>				1	4
LAGERWEY WINDTURBINE BV		Beheerder:				2	5
Hanzeweg 31 3771 NG Barneveld Tel.: 0342 422724 / Fax: 0342 422861		Ref.: NEN - ISO 9001-4.5				b : 05-01-94	
		Nummer:	Blad:	Datum:	Wijz.:	c : 11-07-94	
		E- ES - 2116	-4 e	11 of 11	12-01-93	d : 24-10-94	
						e : 30-12-94	




VIEW UPPER SIDE

Controlhousing

Eurp. proj:	Benaming :	HOLES IN FLOOR FOR THE CONTROLHOUSING			Ref.: NEN - ISO 9001-4.5
	LAGERWEY WINDTURBINE BV	Opsteller: K.W.	Gekontroleerd: J.R.	Beheerder: J.R.	
Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Nummer: <b>E-ED-2069a</b>	Blad : ...1..van...1..	Datum: 29-8-91	Wijz.: a : 17-02-93	

Diagram option smokedetector 80 kW (fat printed)



Eurp. proj.	Benaming :	Wiring diagram Smoke detector 80 kW Plc			Ref.:
					NEN - ISO 9001-4.5
	LAGERWEY WINDTURBINE BV Postbus 279 3770 AG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: W.J. <i>WJ</i>	Gekontroleerd: <i>WJ</i>	Beheerder:	
	Nummer: <i>WJ</i>	Blad : 1 / 1	Datum: 09-11-95	Wijz.:	
	E- EB-2321				

Capacitor-Coil utilization ABB generator for LW 18/80  
with suction filter

Generator:	three-phase short-circuited-armature	Voltage:	400 V
Type:	M2CA 280 SA-4	Freq.:	50 Hz
Power:	75 kW	Efficiency full load:	94,6 %
Kind of operation:	S1	Cos phi full load:	0,84
Nominal revolutions:	1483 rpm	Isolation material:	class: F
Nominal torque:	482,9 Nm	Ambient temp.:	40° C
Nominal current:	136,2 A	Protection:	IP 55
Startcurrent ( Is/In ):	6,9		


Cap.:	Type:	Volt.:	Freq.:	Cap.:	Conn.:	Numb:	Mark:	Function:
C1	12,5 kVar	525 V	50 Hz	3X48,1 µF	delta	4	Esta	Suctionfilter
C2	15 kVar	400 V	50 Hz	3X99,5 µF	delta	1	Esta	Delta low
	8,33 kVar	525 V	50 Hz	3X32 µF	delta	1	Esta	Delta low
C3	12,5 kVar	525 V	50 Hz	3X48,1 µF	delta	1	Esta	Delta high
C4	22 kVar	693 V	75 Hz	3X146 µF	star	3	Esta	Emergency yawing
C5	15 kVar	525 V	50 Hz	3X57,7 µF	delta	1	Esta	Suctionfilter
C6	12,5 kVar	525 V	50 Hz	3X48,1 µF	delta	2	Esta	Suctionfilter

Part nr.: Cap.:

50282	15 kVar	400 V	50 Hz
50271	8,33 kVar	525 V	50 Hz
50273	12,5 kVar	525 V	50 Hz
50270	15 kVar	525 V	50 Hz
50286	22 kVar	693 V	75 Hz

Diagram : EB-.....

Benaming	Capacitor utilization LW 18/80 with ABB generator.	Ref.:	
		NEN - ISO 9001 - 4.5	
 <b>LAGERWEY WINDTURBINE BV</b> Postbus 279 3770 AG Barneveld Tel.: 0342 422724 / Fax: 0342 422861	Opsteller:	Gekontroleerd:	
	W.J. <i>[Signature]</i>	<i>[Signature]</i>	Beheerder:
	Nummer:	Blad:	Datum:
	V	1 / 1	20-02-95
	WI 4.9-1.3-1.5-07-E		



Gridconnection  
Distributingboard

Fuses

160 A



type gl

Gridconnection / Control-unit

mtr Vulta 4x50mm²  
mtr Vult 5x50mm²

Proj nr.:	Proj. :			
Eurp. proj.	Benaming :	Opsteller: K.W.	Gekontroleerd: WJ	Ref.: NEN - ISO 9001-4.5
	Gridconnection LW 80	speciaal netfilter		
LAGERWEY WINDTURBINE BV Hanzeweg 31 3770 NG Barneveld Tel.: 0342 422724 / Fax : 0342 422861	Nummer: E-EN- 2082c	Blad : 1 van 1	Datum: 21-10-91	Wijz.: a : 8-10-92 b : 9-12-93 c : 20-1-95

Eurp. proj. 	Benaming : <b>WIRE AND CABLE LIST LW 75/80 DLH</b>			Ref.: NEN - ISO 9001-4.5
	Opsteller: <i>vd</i>	K.W.	Gekontroleerd: J.R. <i>dr</i>	Beheerder: J.R.
	Nummer: <b>E-EL-2091</b>	Blad : ...van...	Datum: 03-07-'92	Wijz.:   



VIEW UPPER SIDE

Controlhousing

Eurp. proj:	Benaming :	HOLES IN FLOOR FOR THE CONTROLHOUSING			Ref:
					NEN - ISO 9001-4.5
LAGERWEY WINDTURBINE BV Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax : 0342-422861	Opsteller: K.W.	Gekontroleerd: J.R.	Beheerder: J.R.		
	Nummer: E-ED-2069a	Blad : ...1 van ...1..	Datum: 29-8-91	Wijz:	a : 17-02-93

These are standard adjusted

DCH : pot. meter direct current high  
 DCL : " " direct current low  
 ACL : " " bottomvoltage(grid)  
 ACH : " " topvoltage (grid)

red led burns by : -bottomvoltage;  
 -topvoltage;  
 -frequency disturbance;  
 -wrong phaseangle;  
 -phase change.


green led burns if everything is O.K.  
 both led's off : no gridsupply

PLC  
 DHL kontakt  
 open = High  
 close = Low  
 C8  
 B  
 K kontakt



X2  
 Ugrid X2.6 => Upause Ulne

650 mV	=>	353 V	204 V
675 mV	=>	366 V	212 V
700 mV	=>	380 V	220 V
725 mV	=>	394 V	228 V
750 mV	=>	407 V	235 V
X2.2.3			
550 mV	=>	299 V	173 V
1100 mV	=>	597 V	346 V



Connection by 6 pulse mutator:

L1 L2 L3



Connection by 12 pulse mutator:

U1 V1 W1 U2 V2 W2

X1  
 Flatcabel connection for coupling with micro processor:  
 1 analogue phase input  
 2-5 digital phase choice (16 possibilities)  
 6 high / low phase input  
 7 free  
 8 + 5 Volt  
 9 freq. proportional with gridvoltage output  
 10 mutator in action output (instead of K kontakt)  
 11-20 zero

X2  
 These are standard adjusted

- 1 zero
- 2 output freq. grid VCO
- 3 voltage of gridbottomvoltage pot. meter (550mV)
- 4 voltage of gridtopvoltage pot. meter (1100mV)
- 5 measured gridvoltage van L4...L6 (ca. 700mV)
- 6 measured netspanning van L1...L3 (ca. 700mV)

X3  
 1 input voltage phase VCO  
 2 zero  
 3 reference phase blockvoltage to grid  
 4 free  
 5 phase VCO output freq.  
 6 phase locked 50 Hz blockvoltage

X4  
 Check of the phase voltages  
 1 tm 6 : 6 pulse mutator  
 1 tm 12 : 12 pulse mutator

Eurp. proj.	Benaming:	<b>MUTATOR P.C.B. CONNECTIONS DIAGRAM KRS 122000</b>			Ref:
					NEN - ISO 9001-4.5
	LAGERWEY WINDTURBINE BV	Opsteller: K.W. <i>[Signature]</i>	Gekontroleerd: J.R. <i>[Signature]</i>	Beheerdeer: J.R.	
Hanzeweg 31 3771 NG Barneveld Tel.: 0342-422724 / Fax: 0342-422861		Nummer: <b>E-EA - 2108d</b>	Blaad: ... of ...	Datum: 09-11-92	Wijz.: a: 16-11-92 b: 19-01-93 c: 09-04-93 d: 28-7-94